

2022-12-22

# OXO-PRO

## LOCKABLE GRIP ASSEMBLY INSTRUCTIONS (COMFORT & PERFORMANCE MODELS)

### WARNING

We recommend you use a professional bicycle retailer to fit these bicycles grips  
The handlebar must confirm to the standard external diameter of 22,2mm  
Maximum torque: 3Nm (2,2 ft-lb)- Do not overtighten  
Re-tighten bicycle grips clamp screws after each bicycle ride

### MOUNTING INSTRUCTIONS

Un tighten the screw on each bicycle grip clamp with a 3mm allen key  
Push out the end plugs from the bicycle grips  
Clean the handlebar with isopropanol/alcohol  
Push the bicycle grips on to the bar so that the inside clamp surface is completely in touch with bar  
Tighten the screws slightly so you can still adjust angel of grip to your optimum position  
Tighten the screw to 3 Nm/2,2 ft-lb. It is correctly fitted if you cannot rotate the grip  
Insert the end plugs